


Reference	Qty	Item number	Description
1		093000039	Starter lever
2		093000041	Slide
3		093000042	Slide
4		093000043	Slide
5		3833073	Washer
6		093000148	Screw
7		093000038	Valve
8		093000018	Washer
9		093500417	Carburetor WT-302
10		004000025	Gasket
11		093000403B	Valve
12		093000036	Gasket
21		093000492	Air filter
22		093000468A	Screw
23		093500419	Cover
24		093000232	Gasket set

per } mod. 935 X
for } mod. 935 DX





16 ■ KIT RIPARAZIONE
REPAIR KIT

22 ● KIT MEMBRANE & GUARNIZIONI
DIAPHRAGM & GASKET SET


Refer ence	Qty	Item number	Description
1		093500114	Spring
2		093500116	Screw
3		375100078	Shutter
4		003300209	Screw
5		093500113	Spring
6		093500471	Shaft
7		035000165	Spring
8		093500269	Screw L
9		093500475	Screw H
10		093500115	Spring
11		035000162	Screw
12		2318191	Cover
13		003300202	Screw
14		003300201	Spindle
15		093500474	Jet
16		094600209	Repair kit
17		093500111	Lever
18		095000164	Circlip
19		003300036	Fittings
20		093500472	Cover
21		003300197	Screw
22		094600210	Diaph.+gasket
23		093500417	Carburetor WT-302

Refer ence	Qty	Item number	Description
1		093000484	Ring
2		093000015	Plate
3		093000141	Screw
4		093000019	Washer
5		004000160	Spring
6		093500479	Clutch
7		094500229	Washer
8		093000137	Screw
9		093000016	Cap
10		093000014	Brake band
11		093000308	Clutch drum
12		093000112	Bearing
13		093000020	Washer
14		093000110	Nut
15		093000011	Brake lever
16		093000012	Pin
17		093000013	Spring
18		004000090	Washer
19		093500511	Guard
20		094500454	Washer
22		093000009	Brake lever
23		093000008	Cover
24		093000138	Screw
25		004400959	Nut
26		093500423	Chain cover






Reference	Qty	Item number	Description
1		093500421	Cap
2		094500054	Gasket
3		004000731	Spring
4		093000482	Gasket
5		093500496	Half crankcase
7		006000315	Washer
8		003300509	Oil suction
9		093000090	Pin
11		093000142	Screw
12		093000083	Pin
13		093000143	Screw
14		093000391	Sponge
15		004000086A	Stud
16		3026004	Ring
17		093500274	Chain tensioner screw
18		093500392	Plate
19		3960045	Screw
20		3049002	O-ring
21		094500064	Spring
22		093500463	Piston pump
23		093500460B	Oil pump
24		093500495	Half crankcase
25		093500507	Crankcase
26		093500014	Bush
27		093500422	Cap
28		094000078	Gasket
29		093500207	Hose
30		093000047	Grommet
31		026400090	Hose
32		094500207	Fuel filter
33		093000049	Support
34		093000494	Gasket
35		093500208	Fuel tank




▲ 23

Refer	Qty	Item number	Description
ence			
1		005000019	Spark plug
2		093000073B	Engine head
3		093500002	Gasket
4		003300015R	Piston ring
5		0033000951	Piston pin
6		093000167	Ring
7		093500032	Piston assy Ø38
8		093500090	Cylinder
9		4098232R	Key
10		3037009	Bearing
11		093000088	Gasket
12		093000030	Gasket
13		093000289	Muffler
14		093500332	Screw
15		094000099R	Seal ring
16		006000103	Washer
17		093000147	Screw
18		093000549	Guard
19		093000093	Seal ring
20		3025021	Ring
21		094000006	Bearing
22		093500132	Crankshaft
23		093000232	Gasket set
24		3833073	Washer



Refer	Qty	Item number	Description
ence			
2		093500506	Button
3		093000139	Screw
4		005400599	Washer
5		093000146	Screw
6		3960040R	Screws
11		3801037	Screw
12		093000149	Screw
13		3072015	Washer
14		3033074	Washer
15		093000054	Support
16		093000055	Pipe
18		3914003	Nut
19		093000141	Screw
21		093000498	Support
22		2317021R	Switch
24		072700176	Screw
25		093500420	Cable
26		093500505	Throttle
27		093500500	Cover
28		093500026	Rod
29		093500426	Handle
30		093500509	Handle
31		093500403	Cover



www.oleomachina.com

Refer	Qty	Item number	Description
ence			
1		093000140	Screw
2		093500494	Starter case
3		093500397	Handle
4		4098073R	Starter rope
5		072700089	Bushing
6		043300092	Support
7		004000132R	Spring
8		094000033AR	Starter pulley
9		011200018	Screw
10		3918005	Washer
11		3960040R	Screws
12		093500425	Starter assy
13		004000436R	Pin
14		004000140	Pawl
15		004000139	Spring
16		093000459	Flywheel
17		3912009	Nut
18		005000361	Washer
19		004000442	Screw
20		006000315	Washer
21		3916004	Washer
23		004000189	Spark plug cap
24		093500291	Cable
25		093500358	Ignition coil
26		094600169	Spring
27		094600097A	Spark plug cap
28		093500634	Cable