



FINO A NOVEMBRE 2004
TILL NOVEMBER 2004
BIS NOVEMBER 2004
HASTA NOVIEMBRE 2004
JUSQU'A NOVEMBRE 2004

16 ■ KIT RIPARAZIONE
REPAIR KIT
22 ● KIT MEMBRANE & GUARNIZIONI
DIAPHRAGM & GASKET SET




DA NOVEMBRE 2004
FROM NOVEMBER 2004
AB NOVEMBER 2004
DESDE NOVEMBRE 2004
DEPUIS NOVEMBRE 2004

16 ■ KIT RIPARAZIONE
REPAIR KIT
22 ● KIT MEMBRANE & GUARNIZIONI
DIAPHRAGM & GASKET SET




Refer ence	Qty	Item number	Description
1	1	094600148	Spring
2	1	074000240	Adjust.screw
3	1	095000141	Shutter
4	4	003300209	Screw
5	1	094600208	Spring
6	1	50050112	Shaft
7	1	035000165	Spring
8	1	50050104	Screw L
9	1	50050105	Screw H
10	1	093500115	Spring
11	4	035000162	Screw
12	1	2318191	Cover
13	1	003300202	Screw
14	1	003300201	Spindle
15	1	50050115	Spring
16	1	094600209	Repair kit
17	1	50050111	Lever
18	1	50050109	Bushing
19	1	003300036	Fittings
20	1	50050107	Cover
21	1	003300197	Screw
22	1	094600210	Diaph.+gasket
23	1	50050260	Carburetor WT-562
24	1	094600140	Shutter
25	1	50050117	Screw
26	1	50050113	Shaft
27	1	50050110	Bushing
28	1	50050108	Throttle lever
29	1	50050121	Screw guide
37	1	2318942	Screw L
38	1	2318943	Screw H
39	1	2318695	Cap
40	1	2318694	Cap





Reference	Qty	Item number	Description
1	1	50030372	Bearing
2	1	50050136A	Chain sprocket 3/8
3	1	004000352	Washer
4	1	094500029	Spring
5	1	094000129AR	Clutch
6	1	3960070	Screw
7	1	50050125R	Plate
8	1	50050039	Brake band
9	1	3026003	Ring
10	1	097000146	Lever
11	1	50052002AR	Chain cover
12	1	097000106	Pin
13	1	50050064	Pin
14	2	50010148R	Nut
15	1	50050040	Guard
16	1	50010088AR	Spring
17	1	50050066	Pin
18	1	095000219	Spring
19	1	004400285	Washer
20	1	50050025	Worm gear 3/8

Drawing Crankcase and air filter




Drawing Crankcase and air filter

Reference	Qty	Item number	Description
1	1	50052005R	Tank cap
2	1	3049025	O-ring
3	2	50070067A	Rod
4	4	50050067	Spacer
5	1	50052006A	Oil filter
6	1	097000229R	Breather valve
7	4	3833073	Washer
8	4	3860096	Screw
9	1	094600369R	Guard
10	1	094600041R	Screw
11	1	50050269B	Starter lever
12	1	50050133	Tensioner kit
13	1	50050260	Carburetor WT-562
14	1	50050121	Screw guide
15	1	50050049R	Hose
16	1	50050037	Cover
17	3	3960074	Screw
18	2	3960057R	Screw
19	1	50050020R	Oil pump
20	1	50060091R	Crankcase
21	2	50050052	Stud
22	1	3933100R	Nut
23	1	50050171	Knob
24	1	2317021R	Switch
25	1	50050036AR	Air filter
25	1	50050331R	Air filter optional
26	1	50050034	Knob
27	1	50050035B	Support
28	1	2317013	Guard
29	1	50062023	Spike
30	1	50050122	Guard




Refer ence	Qty	Item number	Description
1	1	3055114	Spark plug
2	2	50050032	Screw
3	4	3801047	Screw
4	2	3960073	Screw
5	1	3050022R	Seal ring
6	2	50110043R	Spacer
7	2	004900061R	Ring
8	1	50050222	Piston pin
9	1	094600103	Band
10	1	50110045R	Crankshaft
11	2	50060076	Gasket
12	1	50050010	Manifold
13	2	3933100R	Nut
14	2	094000006	Bearing
15	1	50050027A	Muffler
16	1	004000015R	Piston ring d.40
17	1	50060027A	Piston assy Ø40
18	1	50060028B	Cylinder
19	1	3037013	Bearing
20	1	3050024R	Seal ring
21	1	50050001	Crankshaft
22	1	50050016R	Cover
23	1	50110044	Needle roller bea
24	1	50110047R	Piston pin
25	1	50120034	Piston assy
26	1	50060103	Ompl. cylinder Ø40



Reference	Qty	Item number	Description
1	3	097000061A	Screw
2	3	50050047	Spring
3	1	50052044	Carb/throttle s
4	1	50050214	Cover
5	1	097000028R	Throttle spring
6	1	50050123R	Strap
7	1	50120029R	Fuel tank
8	2	50052005R	Tank cap
9	2	3960073	Screw
10	2	3049025	O-ring
11	1	094600450R	Fuel filter
12	4	094600041R	Screw
13	1	3960057R	Screw
14	1	50050070A	Hose
15	1	50050046AR	Lever
16	2	50010061R	Shock absorber
17	1	3918010	Washer
18	1	50050072	Cap
19	1	094500575R	Spring
20	1	094500577A	Valve
21	1	50050071	Breather valve
22	3	50050182R	Support
23	1	50070197A	Knob
24	1	50050044A	Throttle rod
25	2	3059017	Band
26	1	50050119	Plate

Drawing Starter assy



3
 Kit etichette
 Labels set
 Jeu étiquette
 Juego etiquetas
 Etikettenkit

Drawing Starter assy

Refer ence	Qty	Item number	Description
1	1	097000064A	Handle
2	1	50070123R	Starter rope
3	1	50060031	Labels kit
4	1	50050073R	Spring
5	1	50050017AR	Starter pulley
6	1	094500034R	Washer
7	1	50050240R	Flywheel
8	1	3960057R	Screw
9	1	50110086	Starter assy
10	1	3960082B	Screw
11	1	006000315	Washer
12	1	3916004	Washer
13	1	50050081	Cable
14	1	50050148	Plate
15	1	50050261	Nut
16	1	3833080	Washer
17	1	005000361	Washer
20	1	50050013AR	Ignition coil
21	1	50050127	Spring
22	1	3960075	Screw
23	1	005000347A	Grommet
24	1	50050126	Spark plug cap
25	1	50072029	Pawl
26	1	50050124	Spacer
27	1	50110087	Starter assy