



1 WALBRO WYK 26A



- 5 ● KIT MEMBRANE & GUARNIZIONI
DIAPHRAGM & GASKET SET
- 6 ■ KIT RIPARAZIONE
REPAIR KIT

Refer ence	Qty	Item number	Description
1	1	2318560R	Carburetor WYK-26A
2	2	2318578	Cap
3	1	2318580	Screw
4	1	2318581	Support
5	1	2318590	Gasket set
6	1	2318591	Repair kit
7	1	2318588	Washer
8	1	035000165	Spring
9	1	2318586	Screw H
10	1	003300204	Fuel filter
11	1	2318589	Seal ring
12	1	2318577	Adjuster nut
13	1	2318583	Screw
14	1	2318189	Ring
15	1	2318579	Valve
16	1	2318567	Pump body
17	1	2318568	Spring
18	1	003300200	Compensator
19	1	2318569	Screw
20	1	003300201	Spindle
21	1	2318570	Pump body
22	1	2318592	Valve
23	4	2318585	Screw
24	1	2318572	Fuel pump
25	1	2318571	Cover


Walbro WYL-159A




● 2 KIT MEMBRANE & GUARNIZIONI
DIAPHRAGM & GASKET SET

■ 3 KIT RIPARAZIONE
REPAIR KIT

Reference	Qty	Item number	Description
1	2	2318954	Screw
2	1	2318590	Gasket set
3	1	2318591	Repair kit
4	1	2318577	Adjuster nut
5	1	2318189	Ring
6	1	2318958	Valve
7	1	2318567	Pump body
8	1	2318569	Screw
9	1	003300201	Spindle
10	1	003300201	Spindle
11	1	2318592	Valve
12	4	2318585	Screw
13	1	2318572	Fuel pump
14	1	2318571	Cover
15	1	2318947R	Carburetor WYL-205




Refer ence	Qty	Item number	Description
1	1	4160125	Starter rope
2	1	4161264B	Flywheel
3	1	4191020A	Handle
4	1	3024018R	Ring
5	1	4161150R	Ring
6	1	4161148A	Pulley
7	1	004000132R	Spring
8	1	61060019	Starter case
9	1	4161160AR	Starter assy
10	1	4160072R	Spacer
11	4	3801011	Screw
12	1	4161570	Short block
13	4	3916005	Washer
14	4	3819006	Washer
15	4	3801009	Screw
16	2	4161151	Pin
17	1	4138441	Pawl
18	1	4161186A	Spring
19	1	4138722R	Ignition coil
20	1	4098064R	Spark plug cap
21	1	4160146A	Deflector
22	2	3916004	Washer
23	2	3819005	Washer
24	2	3801003	Screw
25	1	4161569	Cable
26	1	3916005	Washer
27	1	4160076A	Muffer cover
28	2	3806028	Screw
29	1	4095211R	Plate
30	1	61010011	Gasket
31	1	072700048R	Piston ring Ø34
32	1	3801010R	Screw
33	2	4160025R	Ring
34	1	4161030B	Piston assy Ø34
35	1	005000019	Spark plug
36	1	4098232R	Key
37	2	3064005AR	Washer
38	1	3024010R	Snap ring
39	1	3037006	Bearing
40	1	4161275	Connecting rod
41	1	4160479R	Crankshaft
42	1	61150018	Muffer
43	1	3035040R	Bearing
44	2	3025019	Ring
45	1	3035023	Bearing
46	1	4160124	Washer
47	1	3050007	Seal ring
48	1	4160074C	Cover
49	4	3801015	Screw




Refer	Qty	Item number	Description
ence			
50	1	3819006	Washer
51	1	4160026R	Pin

Drawing Fuel tank and air filter



Drawing Fuel tank and air filter

Reference	Qty	Item number	Description
1	1	61160011	Cover
2	2	61052009B	Screw
3	2	3833073	Washer
4	1	61160014	Air filter
5	1	61162007R	Filter support
6	1	2318947R	Carburetor WYL-205
7	1	4161438	Gasket
8	1	4160428	Insulator
9	1	4160294	Gasket
10	2	3801047	Screw
11	1	3819006	Washer
12	1	61162017A	Air filter kit
13	1	61060012A	Hose
14	1	4161211	Bush
15	1	61152006	Cap
16	1	61060011A	Support
17	1	4098377	Clip
18	1	3801017R	Screw
19	1	3918005	Washer
20	1	094600450R	Fuel filter
21	2	3960057R	Screw
22	1	61152005	Tank
23	1	4138489	Hose
24	1	4138388	Gasket
25	1	4098658AR	Breather valve
26	1	3049040	O-ring
27	1	61150023	Flange



Refer ence	Qty	Item number	Description
1	1	61060004	Joint
2	1	071000016R	Drive shaft
3	1	60012079AR	Tube Ø22
4	1	3024010R	Snap ring
5	1	004400285	Washer
6	1	60012002	Hub
7	2	3979017	Screw
8	1	071000005	Pin
9	1	070000192	Cover
10	1	3064004A	Washer
11	1	3024012	Ring
12	1	071000010A	Spring
13	1	61062006R	Nylon spool
14	2	070000193R	Bushing
15	1	071000006B	Knob
16	1	61062023A	Nylon head Ø2
17	1	3915006	Nut
18	1	3916006	Washer
19	1	3906053	Screw
20	1	4162042A	Handle
21	1	3801010R	Screw
22	1	3916005	Washer
23	1	4174275	Blade
24	1	3960014	Screw
25	1	61062012	Guard assy
26	3	3914003	Nut
27	1	61062027	Complete handle
28	4	3801013	Screw
29	1	61060008	Bushing
30	1	61130006	Throttle cable
31	1	4162267A	Cable
32	1	2317021R	Switch
33	1	61060003AR	Throttle lever
34	1	61060007	Spring
35	1	3933058	Screw
36	1	3960064AR	Screw
37	4	61150012	Spacer
38	4	3918010	Washer